

**ASCENSION**  
POWERED BY ASCENT ADMINISTRATION

# LUXURY & EXOTICS

---

PREMIUM PROTECTION PLANS

---

Your worry-free driving  
journey starts now.



Our best-in-class program offers three coverage tiers and an expansive list of additional benefits.

*All services are subject to maximum reimbursement limits. Coverage may not be available in all states. Restrictions & Limitations may apply.*

## PREMIER COVERAGE

This unparalleled level of coverage includes all the parts & components outlined in BOTH our Executive and Elite plans.



In addition, it extends to every original factory-equipped mechanical and electrical component, excluding only those specified in the Terms & Conditions of your contract.



## ELITE COVERAGE

Includes everything listed under our Executive Plan, plus these additional items:

**SUSPENSION:** Upper and lower control arms and bushings, if bushings cannot be replaced individually; ball joints; leaf and coil springs only if broken.

**STEERING COMPONENTS:** Power steering gearbox; rack and pinion; and high-pressure lines. Steering box, rack and pump housing only if damaged by a lubricated part internal to that covered component.

**BRAKE COMPONENTS:** Power brake booster; master cylinder; calipers; ABS hydraulic components; proportioning valve; ABS wheel speed sensors.

**ELECTRICAL COMPONENTS:** Starter motor and solenoid; alternator, voltage regulator; electric cooling fan motor; distributor; power window motors/switches; power door lock actuators/switches; power trunk or tailgate actuator and motor; all manually operated switches; ignition control module; & cruise control assembly.

**AIR CONDITIONING & REFRIGERANT:** Compressor; clutch; condenser; accumulator/receiver drier; and evaporator. Refrigerant is only covered with a covered repair.

**FUEL:** Fuel pump; fuel injectors; lift pump; transfer pump; MAP/air charge temperature sensor; intake manifold pressure sensor; and throttle position sensor.

## EXECUTIVE COVERAGE

**ENGINE:** Cylinder block, internal parts, cylinder head assemblies, timing case/cover, timing chain/belt, tensioners, gears, sprockets, guides, serpentine belt tensioner, harmonic balancer, oil pump, intake manifold, flywheel with starter ring gear, core plugs, valve covers, oil pan, factory-installed turbocharger/supercharger (including internal parts and wastegate actuator), oxygen sensor, mass airflow sensor, crank sensor, cam sensor. Seals and gaskets are covered only for listed components.

**AUTOMATIC TRANSMISSION:** Transmission case and internal parts, bell housing, transmission pan, torque converter, drive/flex plate, transmission range switch, speed/pressure sensors, PRNDL position switch, transmission control module, valve body, mechatronics unit, conductor plate, servo assemblies, transmission cooler, seals, and gaskets for listed components. Includes reprogramming/re-flash up to \$150 per authorized claim. Bell housing covered if damaged by a covered internal component.

**MANUAL TRANSMISSION:** Main shaft, counter shaft, all gears, chain, input shaft, hub assemblies, synchronizers, shift rails, shift fork, internal transmission bearings. Transmission case only if damaged by a covered internal component. \*Note: Clutch parts are not covered.\*

**ENGINE COOLING SYSTEM:** Water pump, housing, fan clutch, radiator.

**FRONT WHEEL DRIVE:** Transaxle case and internal parts, axle shaft assemblies, CV joints/boots, differential cover, speed sensors, solenoid assembly, electronic controller, wheel bearings/hub assemblies, seals, and gaskets for listed components. Transaxle case covered if damaged by a covered internal component.

**REAR WHEEL DRIVE:** Rear axle housing & internal parts, axle shafts, axle shaft bearings, drive shaft assemblies, universal joints/yokes, center bearings, wheel bearings/hub assemblies, seals, and gaskets for listed components. Rear axle housing covered if damaged by a covered internal component.

**FOUR-WHEEL DRIVE (4x4):** Transfer case and internal parts, control module, shift mode motor, axle housing and internal parts, axle shafts, axle shaft bearings, drive shafts (front and rear), center bearings, universal joints, 4x4 hubs, yokes, wheel bearings/hub assemblies, disconnect housing assembly, seals, and gaskets for listed components. Transfer case housing covered if damaged by a covered internal component.

**FLUIDS:** Covered only when required for a covered component.

**SEALS & GASKETS:** If under 100,000 miles at the time of claim, seals and gaskets are covered for leakage related to listed components.

## 24/7 ROADSIDE SERVICES + VALUE-ADDED BENEFITS



### EMERGENCY FLUID DELIVERY

We deliver essential fluids to get you back on the road, such as fuel, oil, and/or water (cost of fluids not included).



### FLAT TIRE ASSISTANCE

Up to \$50 per occurrence towards the replacement of a flat tire with your inflated spare. You are responsible for the actual costs to repair or replace a tire.



### DEAD BATTERY JUMP-START

Up to \$50 per occurrence for jump-starting a dead battery (not available for hybrid vehicles).



### LOCKOUT SERVICE

Up to \$50 per occurrence for on-location assistance if you lock your keys/fob in your vehicle or if they are lost/broken (key/fob replacement cost not included).



### TOWING

Up to \$200 per occurrence for towing to the nearest qualified repair facility.



### RENTAL BENEFITS

Up to \$75 reimbursement per 6 hours of labor time, with a max benefit of \$450 per claim, provided for authorized repair work (time unrelated to authorized repairs not included).



### TRIP INTERRUPTION

Up to \$150 reimbursement per day for up to 3 days towards meals and/or lodging expenses is provided if you are more than 100 miles away from home and unable to operate your vehicle due to a covered mechanical breakdown.



### LABOR & DIAGNOSTICS

Repair facility labor and/or diagnostic charges associated with a covered repair\*. (Your authorization may be required).